



Software UI


Open the software once the keyboard is connected to your computer.




On the top is the menu bar, functions are on the left, and the skin and settings buttons are in the top right corner of the software interface. The configuration files bar below the menu bar has four buttons

    to add a file, delete a file, export, and import a configuration file

respectively. Click this symbol  to access “Config1” configuration file. You can add several configuration files. The current configuration file will be highlighted.


Click  to bind a configuration file with a specific computer program. For example, if you bind Microsoft Word with “Config1”, your keyboard will automatically switch to the “Config1” when you open a Microsoft Word file.

Custom




Click “CUSTOM” on the menu bar to enter the custom page.

Click one of the keys, and then click the keyboard button in the left functions bar. Click the entry bar and then press any key on your keyboard to change the function of that specific key. You can change the function, add a shortcut or even disable a key on your keyboard. When the customization is done,


click  on the bottom right corner to apply your settings. If you want to restore this key, click the delete icon in the orange prompt.

RGB Light Effects




Click “LIGHT EFFECT” on the menu bar to enter the lighting effect page.

Choose different colors for multiple preset lighting modes.




You can change the lighting effect speed, brightness and direction for some of the preset lighting modes. For the customizable lighting mode, you need to use your keyboard to customize. Click the apply button when the customization is done.

Macro Recording



Click "MACRO" on the menu bar to enter the macro page.

Click the plus button  to add a macro "Macro1". You can rename the macro in the name bar to avoid confusion. Choose from three recording delays: the realtime recording delay, the 5ms delay or the customizable delay. Click "Starting recording" button to record the key combinations you frequently use when gaming. Click the same button to stop recording.




You can change the delay and the keys after you stop recording. Click these two buttons




to delete, import, or export a macro. Once you delete a macro, it will be permanently deleted for all your configuration files.

Macro Application



After recording the “Macro1”, open the custom page and choose the macro button on the left. Choose “Macro1” from the drop-down list and select the play mode of the key combinations.



Type the play times for one key press. Then click the button  and the Apply button.

Macro play mode:


1. Release the key to stop macro

Long press the key to play the macro and release the key to stop playing before the macro finishes playing.

2. Press any other key to stop macro


Short press the key to play the macro and press any other key to stop playing before the macro finishes playing.

Statistics



Click "STATISTICS" on the menu bar to enter the statistics page.

Click the start button on the bottom right corner to start calculating the keystrokes.



Click the button to stop calculating and find out the keystrokes during the calculation.