

If your AUKEY DR01 dash camera won't boot normally, try pressing the reset button on the camera with a pin. If the camera still won't boot:

1. Take the microSD card out of the dash camera and format it on your computer. Backup important videos and photos on the card before formatting (all files will be permanently erased).
2. Download the "DR01 Firmware" zip file from www.aukey.com/downloads. Copy the "FWDR01H.bin" file to the root (top level) folder of the microSD card. Don't change the file name.
3. Insert the microSD card into the dash camera. Power on the camera and wait while it boots and installs the new firmware.