Caution

- NOT waterproof, please keep away from water, liquid and moisture.
- Keep away from fire, direct sunlight and extreme heat.
- Dispose of battery in accordance with local environmental laws.

Warranty

AUKEY provides a 24 Month Warranty on all products starting from the date of original purchase. If the device fails due to manufacturer defects, please contact us to launch a warranty claim with your order number at:

support@aukey.com (US Amazon orders) or support.ca@aukey.com (Canada Amazon orders)

For all other inquiries, please contact our support team at the applicable address above. Be sure to include your order number so we can provide you with the best service and resolve your issue quickly.

For products not purchased through Amazon, please contact the point of sale where you purchased your product for service claims. AUKEY International Ltd. www.aukey.com | support@aukey.com No.102, Building P09, Electronic Trade Center Huanan City, Pinghu Town, Longgang District Shenzhen, Guangdong 518111 CN



Introduction

Thank you for choosing the AUKEY 5 Remote Control Outlets with 2 Remote Controls . Please read this manual carefully as it contains some important information. If you need any further assistance, please contact our customer support at support@aukey.com.

Package Contents

- 5x AUKEY 5 Remote Control Outlets with 2 Remote Controls
 Control Electrical Outlet Switchs
- 2x Remote Controls
- 1x Dry Battery
- 1x Warranty Card
- 1x User Manual

Technical Specification

Model	PA-R2
voltage	120V/60HZ
Current	15A
power	1800W(Max)
Remote Control Distance	100'

How to use?

1. Program The Remote Control Outlet

- 1) Open the back cover of the handhold remote control to install the included battery.
- 2) Plug the remote control outlet into AC wall outlet, and press the button on the outlet, LED indicator will turn on.
- 3) Press and hold the button on remote control outlet for 3 seconds until LED indicator flashes slowly, then press any desired number button (ON or OFF) on the handhold remote control, the outlet's LED indicator will flash quickly for 2 seconds. The socket is now programmed to the corresponding number you selected on the remote control.
- 4) Additional remote control buttons(up to 5) can be added to control additional outlets simultaneously.

2. Remotely Control the Electrical Appliance

 Press the programed ON / OFF button on handhold remote control to turn on or turn off the electrical appliance plugged on the remote control outlet.

- Press the ALL ON / OFF button on handhold remote control to turn on or turn off all electrical appliances plugged on the remote control outlet at once.
- Press the button on remote control outlet to turn on or turn off the electrical appliance.

3. Reset Single Button Operation

1) To reset a numbered button on the remote control for an individual outlet

Press and hold the button on remote control outlet for approximately 7 seconds, the LED indicator on the outlet will blink slowly, quickly, then slowly, and the individual outlet will be reset and decoupled from the remote control.

2) Reset all outlets once

Press and hold the ALL OFF button on the handhold remote control for approximately 7 seconds, the LED indicator light on the outlets will start blink quickly, then slowly, then all remote control outlets will be reset.

 To re-program any or all of the outlets, please resume the programming process from step 1.



